


Ljud i byggnad och samhälle (VTAF01)

– Mätteknik



Juan Negreira

Konceptutvecklare
Gästföreläsare

– Ecophon (Spanien)
– Lunds Universitet (Sverige)



juan.negreira@construction.lth.se



@JNegreira_db




Juan Negreira

Ecophon®
SAINT-GOBAIN
A SOUND EFFECT ON PEOPLE





LUND
UNIVERSITY

Outline




Why do we measure?



Introduction (I)

- Paradigm of natural sciences



- Theory: explained and generalised experimental results
- Prediction: use theory to predict consequences
- Experiment: observation / measurement of phenomena




Introduction (II)

Eisenhart [1876-1965]: “*To measure is to assign numerical values to concepts of physical quantities to symbolise the relations which exist between them regarding special properties*”




Introduction (III)



- Experimental process to acquire new knowledge of a “product”
- Planned actions for quantitative comparison of a measurand with an unit
- Measurand: physical quantity to be measured
- Measurement equipment: software, standards, apparatus...




Outline




Signals

- Acquisition: voltage-time
 - Unequivocally related to the measurand



- Noise: changes the smooth signal to a “jagged” curve




- Signal to noise ratio (SNR)
 - $SNR > 1$ means *Signal > Noise*
 - Filtering

$$SNR = \frac{P_{signal}}{P_{noise}}$$







$$SNR_{dB} = 10 \log_{10} \frac{P_{signal}}{P_{noise}}$$

Getting ready for the analysis


- To get the signal into a computer, one needs to digitalise it
- Digitalise (also called digitise): conversion from analogue signal to a stream of discrete values (numbers)
- Δt between two consecutive values: given by sampling frequency



Sampling frequency



- The red dots (samples) do not truly represent the signal
- How to select an appropriate sampling frequency?



NYQUIST-SHANNON CRITERION

sampling frequency must be twice the higher frequency in the signal



Nyquist-Shannon sampling criterion

Let $x(t)$ be a continuous-time signal and $X(f)$ its FT

$$X(f) \stackrel{\text{Def}}{=} \int_{-\infty}^{+\infty} x(t) e^{i 2 \pi f t} dt$$

$x(t)$ is said to be bandlimited to a one-sided baseband bandwidth, B , if:

$$X(f) = 0 \quad \forall \quad |f| > B$$


The sufficient condition for “exact” reconstructability from samples at uniform sample rate is:

$$f_s > 2B \Leftrightarrow B < \frac{f_s}{2} \quad ; \quad T \stackrel{\text{Def}}{=} \frac{1}{f_s}$$


$2B$ is called the Nyquist rate and it is a property of the band-limited signal, while $(f_s/2)$ is called the Nyquist frequency and is a property of the sampling system

Aliasing

- If Nyquist-Shannon criterion is not fulfilled (bad sampling)
 - Two different continuous signals become indistinguishable




- Example: Helicopter: Stroboscopic effect
- Example: Image aliasing (Sampling / Pixel density wrong)




How to analyse the data?

- Waveform: amplitude as a function of time
- Spectrum: frequencies contained in the signal
- Leap between domains: FT
- In practice, software apply FFT



(a) Time domain.



(b) Frequency domain.





LUND
UNIVERSITY


FFT example (Matlab)

```
%Juan Negreira; May 2011
%Calculates the discrete fourier transform of the timedomain signal y(t)
%Y:amplitude of the frequency components
%f:freqencies[Hz]
%Only the unique points are returned ie. f lies in 0 <= f <= Fs/2

%% Introducing the time signal
dt=1/100;
et=4;
xData=0:dt:et;
yData=3*sin(4*2*pi*xData);
%% Calculating the FFT
%Number of points in input data
NFFT=length(yData);
%Nyquist frequency
Fn=1/(xData(2)-xData(1))/2;
%Absolute value of the FRF
FFTY=abs(fft(yData));
NumUniquePts=ceil((NFFT+1)/2);
% fft symmetric, throw away second half
FFTY=FFTY(1:NumUniquePts);
% Take magnitude of Y
Yfft=abs(FFTY);
% Multiply by 2 to take into account the fact that we
% threw out second half of FFTY above
Yfft=Yfft*2;
% Account for endpoint uniqueness
Yfft(1)=Yfft(1)/2;
% We know NFFT is even
Yfft(length(Yfft))=Yfft(length(Yfft))/2;
% Scale the FFT so that it is not a function of the length of y.
Yfft=Yfft/length(yData);
%Frequencies
freq=(0:NumUniquePts-1)*2*Fn/NFFT;
%% Plotting time signal and FFT
subplot(2,1,1)
plot(xData,yData); grid on
axis([0 et -8 8])
xlabel('Time [s]'); ylabel('Amplitude')
subplot(2,1,2)
plot(freq, Yfft);grid on
xlabel('Frequency [Hz]'); ylabel('Amplitude')
```




FFT example (Matlab)



LUND
UNIVERSITY


FFT example (Matlab)





- Example: [video](#)

Resonance – Definition

- Resonance (def.):
 - Tendency to oscillate at a greater amplitude at some frequencies
- Depends on:
 - Mass
 - Stiffness
 - Damping
- Examples:
 - Earthquake design
 - Bridges (Tacoma & Spain)
 - Cup
 - Plate (mode shapes)



Resonance – Standing waves



- Incident sound wave
- Reflected sound wave
- Resultant (standing) wave

"HOMEWORK"

Example/explanation resonance: <https://youtu.be/LfagUvs4Lns>


Reverberant/anechoic chamber: <https://youtu.be/M7JD87vomgs>

Standing waves in a string: resonances & eigenmodes



$$\lambda=2L$$
$$f_1=v/2L$$

Fundamental eigenfrequency / 1st harmonic



$$\lambda=L$$
$$f_2=2f_1$$

Second eigenfrequency / 2nd harmonic

In general:

$$\lambda=2L/n$$
$$f_n=n\cdot v/2L$$




$$\lambda=(2/3)L$$
$$f_3=3f_1$$

Third eigenfrequency / 3rd harmonic

Eigenmode: different ways a string (structure in general) can vibrate generating standing waves
Examples: 1 / 2 / 3 / 4.

Outline




Excitation sources (floor vibrations)

- Standardised
 - Tapping machine
 - Rubber tire




- Non-standardised
 - Shaker
 - Japanese ball
 - Impact hammer
 - Human walking
 - ...




Excitation sources (acoustics)

- Standardised
 - Loudspeakers (noise)
- Non-standardised
 - Cap-gun
 - Baby-crying
 - Impulse



Outline



Sensors and transducers

- Transducers: detection
- Sensors: detect and communicate
 - Parameters:
 - » Sensitivity: “electrical output / mechanical input”, e.g. [mV/ms⁻²]
 - » Frequency response: sensitivity over whole spectra
 - » Phase response: time delay between input and output
 - » Resolution: smallest input increment reliably detected
 - » Dynamic range: output proportional to input
 - » Saturation: maximum output capability
 - » Weight < 0.1 x weight specimen to be measured
 - » Environmental characteristics: temperature, humidity...
 - » Repeatability / Reproducibility
 - » Eccentricity


Calibration (I)

- What is it?
 - Comparison between the value indicated in a device and a reference known value
- Why calibrate?
 - Repeatability
 - Transference
 - Equipment exchange
 - Fulfillment of quality standards



Calibration (II)

- Examples:
 - Sound level meter:
 - Accelerometers:



Microphones (I)


- Acoustical-to-electric transducer (sound → electric signal)
- Scalar pressure sensors with an directional-dependent response



LUND
UNIVERSITY

Microphones (II)


- Requirements:
 - Good acoustic and electric performance
 - Minor influence from the environment
 - High stability of sensitivity and frequency response
 - High suitability for measurement
 - Comprehensive specifications and performance description.



Microphones (III)

Microphones' directionality (polar plots)


- Microphone's sensitivity to sound from various directions
 - Omnidirectional
 - Unidirectional (e.g. cardioid and hypercardioid)
 - Bidirectional



LUND
UNIVERSITY

Microphones (IV)

Directional Characteristics



www.bksv.com, #0558/1



Brüel & Kjær BEYOND MEASURE



LUND
UNIVERSITY



Microphones (V)

Free Field Correction



Microphones (VI)

Time Weighting



Brüel & Kjær BEYOND MEASURE


www.bksv.com, 31



LUND
UNIVERSITY

Microphones (VII)

Example: iPhone Built-in Microphone Frequency Response






REF: <http://blog.faberacoustical.com/2010/ios/iphone/iphone-4-audio-and-frequency-response-limitations/>



LUND
UNIVERSITY


Accelerometers (I)

- Mechanical, piezoelectric, hall effect, capacitive...



Accelerometers (II)

- Avoiding errors due to accelerometer resonance





Source: [Measuring vibration \(B&K\)](#)



LUND
UNIVERSITY

Accelerometers (III)

- Be aware of the mounting method...




Source: [Measuring vibration \(B&K\)](#)





LUND
UNIVERSITY

Others (I)

- Gyroscopes
 - Measure or maintaining orientation
 - Based on conservation of angular momentum





- LVDT sensors
 - Linear Variable Differential Transformers
 - Output voltage proportional to the displacement of the core






Others (II)



- Pressure sensors
 - Output voltage proportional to the pressure
- Interferometers
 - Output voltage if obstacle detected
- Velocity pickups
 - Voltage proportional to the relative velocity between elements
- Smartphones
 - Different sensors




In-situ vibratory measurements (I)




In-situ vibratory measurements (II)



Note / Reminder




Outline




Errors – Introduction

- Ideal measurements: no errors
- Real ones always do
- Clear defined processes to identify every source of error
- Measurement system errors can only be defined in relation to the solution of a real specific measurement task



VoIA (I)

- Value of Information Analysis (VoIA)
 - How much do I want to “pay” for my information / output?




VoIA (II)

- Value of Information Analysis (VoIA)
 - How much do I want to “pay” for my information / output?

1.234 m



$1.234 \text{ m} \pm 0.017 \text{ m}$



?




The issue of scale...



LUND
UNIVERSITY

Errors in measurements

- Before the measurement:
 - Uncertainty
 - Reliability / Confidence
 - Risk
 - Probability
- After the measurement:
 - Error: $\Delta x = x_{\text{real}} - x_{\text{measured}}$




NOTE: the concept of error presumes a knowledge of the correct value and it's therefore an abstraction







LUND
UNIVERSITY

Quality of measurements

- Lack of systematic deviation from a true value: accuracy
- Bias: average deviation from a true value
- Lack of scatter: precision
 - Repeatability (variability when measuring by 1 person)
 - Reproducibility (variability caused by changing operator)



Accuracy / Bias / Precision



$$\text{Accuracy} = \text{Bias} + \text{Precision}$$

- a) high bias + low precision = low accuracy
- b) low bias + low precision = low accuracy
- c) high bias + high precision = low accuracy
- d) low bias + high precision = high accuracy



Error “chain”

- Measurement system type. Common errors:
 - Input error
 - Sensor error
 - Signal Transmission error 1
 - Transducer error
 - Signal Transmission error 2
 - Converter error
 - Signal Transmission error 3
 - Computer error
 - Signal Transmission error 4
 - Indication error





Figure 1. Measurement chain.



Types of errors (I)

- Systematic error (bias)
 - Permanent deflection in same direction from true value
 - It can be corrected
 - Types:
 - » Lack of gauge resolution
 - » Lack of linearity
 - » Drift (time, temperature...)
 - » Hysteresis



Types of errors (II)



- Gross errors
 - Human mistakes
- Random error
 - Remains after correct gross and systematic errors
 - » It cannot be corrected
 - Short-term scattering of values around a mean value
 - Varies in an unpredictable way
 - Expressed by statistical methods
 - Reasons
 - » Lack of equipment sensitivity
 - » Noise
 - » Imprecise definition

$$X_{true} = X_{measured} + e_{syst} + e_{random}$$



Examples of errors (I)


- Wire error



LUND
UNIVERSITY

Examples of errors (II)



- Music and external impact




LUND
UNIVERSITY

Examples of errors (III)

- Step motor (2 Hz / 4.5 Hz)
 - Harmonic signal?




Outline





Prefabricated wooden buildings

- Timber volume element (TVE)-based building



- Method (to develop numerical prediction tools):
 - Calibration FE model with *in situ* measurements
 - Modify features in the model


FE Model TVE-based building





LUND
UNIVERSITY

Calibration (preliminary results)




- Measurements



- Simulations





T-junctions



- Influence of the use of glue in lightweight timber junctions
 - Investigate how to model connections


Many transducers and
excitation positions!
Document everything



Calibration of the FE models with measurements in terms of modal analyses to understand their behaviour

Wall-floor building element (I)

- Wall-floor element:
 - Dimensions: $9.3 \times 3.6 \text{ m}^2$
 - Connections: glue and screws





- Investigation of reflection and transmission properties
 - Gain knowledge towards FE modelling




LUND
UNIVERSITY

Wall-floor building element (II)

Many transducers and
excitation positions!
Document everything



Measurements



FE simulations

Psycho-vibratory investigation of timber floors

- Subjective: 31 subjects / 5 floors
 - Walking
 - Seated
- Objective measurements






- 310 data files (subjective)
- 30 data files (objective)
- Always planned actions!!



LUND
UNIVERSITY


Flanking transmission

Many transducers and
excitation positions!
Document everything




LUND
UNIVERSITY


EMA of a TVE mockup




(a) 1st mode shape.




(b) 2nd mode shape.




(c) 3rd mode shape.




(d) 4th mode shape.




(e) 5th mode shape.




(f) 6th mode shape.




(g) 7th mode shape.




(h) 8th mode shape.



(i) 9th mode shape.



Outline



Conclusions

- To measure: acquire knowledge of a new product
 - Analyses prior to measurements
 - Measurement plan based on analyses and purpose
- Signals: frequency and time domain
 - Nyquist-Shannon criterion
 - Resonance
- Excitation sources
- Measurement devices
- Errors
 - Measurements: accompanied by a quality statement
- Document the process (pictures, notes...)



Thank you for your attention!



juan.negreira@construction.lth.se



@JNegreira_dB



Juan Negreira



LUND
UNIVERSITY