



LUND  
UNIVERSITY

# Measurement Techniques

---


JUAN NEGREIRA, DELPHINE BARD

DIVISION OF ENGINEERING ACOUSTICS, LUND UNIVERSITY



# Outline

---



# Why do we measure?


---



# Introduction (I)

---

- Paradigm of natural sciences



- Theory: explained and generalised experimental results
- Prediction: use theory to predict consequences
- Experiment: observation / measurement of phenomena



# Introduction (II)


---

Eisenhart [1876-1965]: “*To measure is to assign numerical values to concepts of physical quantities to symbolise the relations which exist between them regarding special properties*”



# Introduction (III)

---




- Experimental process to acquire new knowledge of a “product”
- Process: planned actions for quantitative comparison of a measurand with an unit
- Measurand: physical quantity to be measured
- Measurement equipment: software, standards, apparatus...




# Outline

---




# Signals

- Acquisition: voltage-time
  - Unequivocally related to the measurand



- Noise: changes the smooth signal to a “jagged” curve



- Signal to noise ratio (SNR)
  - $SNR > 1$  means  $Signal > Noise$
  - Filtering

$$SNR = \frac{P_{signal}}{P_{noise}}$$


$$SNR_{dB} = 10 \log_{10} \frac{P_{signal}}{P_{noise}}$$




# Getting ready for the analysis

---

- To get the signal into a computer, one needs to digitalise it
- Digitalise (also digitise): conversion from analogue signal to a stream of discrete values (numbers)
- $\Delta t$  between two consecutive values: given by sampling frequency



# Sampling frequency



- The red dots (samples) do not truly represent the signal
- How to select an appropriate sampling frequency?



## NYQUIST-SHANNON CRITERIA

the sampling frequency must be twice the higher frequency in the signal



# Nyquist-Shannon sampling criterion

---

Let  $x(t)$  be a continuous-time signal and  $X(f)$  its FT

$$X(f) \stackrel{\text{Def}}{=} \int_{-\infty}^{+\infty} x(t) e^{i2\pi ft} dt$$

$x(t)$  is said to be bandlimited to a one-sided baseband bandwidth,  $B$ , if:

$$X(f) = 0 \quad \forall \quad |f| > B$$

The the sufficient condition for “exact” reconstructability from samples at uniform sample rate is:

$$f_s > 2B \Leftrightarrow B < \frac{f_s}{2} \quad ; \quad T \stackrel{\text{Def}}{=} \frac{1}{f_s}$$


$2B$  is called the Nyquist rate and it is a property of the band-limited signal, while  $(f_s/2)$  is called the Nyquist frequency and is a property of the sampling system




# Aliasing

---

- If Nyquist-Shannon criterion is not fulfilled (bad sampling)
  - Two different continuous signals become indistinguishable




- Example: Helicopter: Stroboscopic effect
- Example: Image aliasing (Sampling / Pixel density wrong)




# How to analyse the data?

- Waveform: amplitude as a function of time
- Spectrum: frequencies contained in the signal
- Leap between domains: FT
- In practice, software apply FFT



(a) Time domain.





(b) Frequency domain.




# FFT example (Matlab)

```
%Juan Negreira; May 2011
%Calculates the discrete fourier transform of the timedomain signal y(t)
%Y:amplitude of the frequency components
%f:frequencies[Hz]
%Only the unique points are returned ie. f lies in 0 <= f <= Fs/2
```


```
%% Introducing the time signal
dt=1/100;
et=4;
xData=0:dt:et;
yData=3*sin(4*2*pi*xData);
%% Calculating the FFT
%Number of points in input data
NFFT=length(yData);
%Nyquist frequency
Fn=1/(xData(2)-xData(1))/2;
%Absolute value of the FRF
FFTY=abs(fft(yData));
NumUniquePts=ceil((NFFT+1)/2);
% fft symmetric, throw away second half
FFTY=FFTY(1:NumUniquePts);
% Take magnitude of Y
Yfft=abs(FFTY);
% Multiply by 2 to take into account the fact that we
% threw out second half of FFTY above
Yfft=Yfft*2;
% Account for endpoint uniqueness
Yfft(1)=Yfft(1)/2;
% We know NFFT is even
Yfft(length(Yfft))=Yfft(length(Yfft))/2;
% Scale the FFT so that it is not a function of the length of y.
Yfft=Yfft/length(yData);
%Frequencies
freq=(0:NumUniquePts-1)*2*Fn/NFFT;
%% Plotting time signal and FFT
subplot(2,1,1)
plot(xData,yData); grid on
axis([0 et -8 8])
xlabel('Time [s]'); ylabel('Amplitude')
subplot(2,1,2)
plot(freq, Yfft);grid on
xlabel('Frequency [Hz]'); ylabel('Amplitude')
```



# FFT example (Matlab)



# FFT example (Matlab)




- *Example: [video](#)*




# Resonance

- Resonance (def.):
  - Tendency to oscillate at a greater amplitude at some frequencies
- Depends on:
  - Mass
  - Stiffness
  - Damping
- Examples:
  - Earthquake design
  - Bridges (Tacoma & Spain)
  - Cup
  - Plate (mode shapes)



# Outline

---



# Excitation sources (floor vibrations)

---


- Standardised
  - Tapping machine
  - Rubber tire
- Non-Standardised
  - Shaker
  - Japanese Ball
  - Impact Hammer
  - Human Walking



# Excitation sources (acoustics)


---

- Standardised
  - Loudspeakers (noise)
- Non-Standardised
  - Cap-gun
  - Baby-crying
  - Impulse



# Outline

---



# Sensors and transducers

---

- Transducers: detection
- Sensors: detect and communicate
  - Parameters:
    - » Sensitivity: “electrical output / mechanical input”, e.g. [mV/ms<sup>-2</sup>]
    - » Frequency response: sensitivity over whole spectra
    - » Phase response: time delay between input and output
    - » Resolution: smallest input increment reliably detected
    - » Dynamic range: output proportional to input
    - » Saturation: maximum output capability
    - » Weight < 0.1 x weight specimen to be measured
    - » Environmental characteristics: temperature, humidity...
    - » Repeatability / Reproducibility
    - » Eccentricity



# Calibration (I)

---

- What is it?
  - Comparison between the value indicated in a device and a reference known value
- Why calibrate?
  - Repeatability
  - Transference
  - Equipment exchange
  - Fulfillment of quality standards



# Calibration (II)

---

- Examples:

- Sound level meter:



- Accelerometers:



# Microphones (I)

---



- Acoustical-to-electric transducer (sound  $\rightarrow$  electric signal)
- Scalar pressure sensors with an omnidirectional response



# Microphones (II)




---

- Requirements:
  - Good acoustic and electric performance
  - Minor influence from the environment
  - High stability of sensitivity and frequency response
  - High suitability for measurement
  - Comprehensive specifications and performance description.






# Accelerometers

- Mechanical, piezoelectric, hall effect, capacitive...





# Others (I)

- Gyroscopes
  - Measure or maintaining orientation
  - Based on conservation of angular momentum
- LVDT Sensors
  - Linear Variable Differential Transformers
  - Output voltage proportional to the displacement of the core






# Others (II)

- Pressure Sensors
  - Output voltage proportional to the pressure
- Interferometers
  - Output voltage if obstacle detected
- Velocity Pickups
  - Voltage proportional to the relative velocity between elements
- SmartPhones
  - Different sensors





# In-situ vibratory measurements (I)

Surface Vibrations Tapping Machine




# In-situ vibratory measurements (II)



# Outline

---



# Errors: introduction

---


- Ideal measurements: no errors
- Real ones always do
- Clear defined processes to identify every source of error
- Measurement system errors can only be defined in relation to the solution of a real specific measurement task



# VoIA (I)

---

- Value of Information Analysis (VoIA)
  - How much do I want to “pay” for my information / output?



# VoIA (II)

- Value of Information Analysis (VoIA)
  - How much do I want to “pay” for my information / output?

1.234 m



1.234 m  $\pm$  0.017 m



2 000 000 €



?



# The issue of scale...


---



# Errors in measurements

---

- Before the measurement:
  - Uncertainty
  - Reliability / Confidence
  - Risk
  - Probability
- After the measurement:
  - Error:  $\Delta x = x_{\text{real}} - x_{\text{measured}}$




NOTE: the concept of error presumes a knowledge of the correct value and it's therefore an abstraction



# Quality of measurements





---

- Lack of systematic deviation from a true value: accuracy
- Bias: average deviation from a true value
- Lack of scatter: precision
  - Repeatability (variability when measuring by 1 person)
  - Reproducibility (variability caused by changing operator)



# Accuracy / Bias / Precision

---



$$\text{Accuracy} = \text{Bias} + \text{Precision}$$

a) high bias + low precision = low accuracy

b) low bias + low precision = low accuracy

c) high bias + high precision = low accuracy

d) low bias + high precision = high accuracy



# Error “chain”

- Measurement system type. Common errors:
  - Input error
  - Sensor error
  - Signal Transmission error 1
  - Transducer error
  - Signal Transmission error 2
  - Converter error
  - Signal Transmission error 3
  - Computer error
  - Signal Transmission error 4
  - Indication error





Figure 1. Measurement chain.



# Types of errors (I)

- Systematic error (bias)
  - Permanent deflection in same direction from true value
  - It can be corrected
  - Types:
    - » Lack of gauge resolution
    - » Lack of linearity
    - » Drift (time, temperature...)
    - » Hysteresis



# Types of errors (II)

---

- Gross errors
  - Human mistakes




$$X_{true} = X_{measured} + e_{syst} + e_{random}$$

- Random error
  - Remains after correct gross and systematic errors
    - » It cannot be corrected
  - Short-term scattering of values around a mean value
  - Varies in an unpredictable way
  - Expressed by statistical methods
  - Reasons
    - » Lack of equipment sensitivity
    - » Noise
    - » Imprecise definition



# Examples of errors (I)



- Wire error



# Examples of errors (II)




---

- Music and external impact




# Examples of errors (III)

- Step motor (2 Hz / 4.5 Hz)
  - Harmonic signal?




# Outline

---



# Prefabricated wooden buildings

- Timber volume element (TVE)-based building




- Method (to develop numerical prediction tools):
  - Calibration FE model with in-situ measurements
  - Modify features in the model




# FE Model TVE-based building

---





# Calibration (preliminary results)

- Measurements






- Simulations





# T-junctions

- Influence of the use of glue in lightweight timber junctions
  - Investigate how to model connections



Many transducers and  
excitation positions!  
Document everything




Calibration of the FE models with  
measurements in terms of modal analyses to  
understand their behaviour



# Wall-floor building element (I)

- Wall-floor element:
  - Dimensions: 9.3 x 3.6 m<sup>2</sup>
  - Connections: glue and screws





- Investigation of reflection and transmission properties
  - Gain knowledge towards FE modelling




# Wall-floor building element (II)

Many transducers and  
excitation positions!  
Document everything



Measurements



FE simulations



# Psycho-vibratory investigation of timber floors

- Subjective: 31 subjects / 5 floors
  - Walking
  - Seated
- Objective measurements





- 310 data files (subjective)
- 30 data files (objective)
- Always planned actions!!




Many transducers and excitation positions!  
Document everything

# Flanking transmission



# Outline

---



# Conclusions

---

- To measure: acquire knowledge of a new product
  - Analyses prior to measurements
  - Measurement plan based on analyses and purpose
- Signals: frequency and time domain
  - Nyquist-Shannon criteria
  - Resonance
- Excitation sources
- Measurement devices
- Errors
  - Measurements: accompanied by a quality statement
- Document the process (pictures, notes...)



Thank you for your attention!

[juan.negreira@construction.lth.se](mailto:juan.negreira@construction.lth.se)



**LUND**  
**UNIVERSITY**